

# DVR

user guide

**BLUE VALLEY**  
tele-communications

A world of entertainment in the palm of your hand

## experience DVR

Take Control of your TV experience with the power of DVR! Record any TV program with the touch of a button and watch it whenever you want. Rewind live TV to see what you missed. Pause what you are watching for any interruption or desire. Replay those hilariously funny parts as many times as you want. Record it and watch when it's convenient for you. With your DVR, YOU control the TV schedule.



# mastering the DVR

A world of entertainment in the palm of your hand

## record a program

Press the Guide button to view the program guide. Using the arrow keys, highlight the program you want to record and press the Record button. If you are already watching the program, simply press the Record button to begin recording.

## stop recording

Press the Stop button and follow the on screen directions. If you started the recording using the Guide, recording will stop when the program is finished.

## control a live program

If you want to pause what you are watching, press the Pause button. Need to see something again? Press the Skip Back button.

## watch a recording

Press the My Recordings button to view your list of recorded programs. Use the arrow keys to select the recorded program you want to watch and press Play.

## delete a recording

Press the My Recordings button. Use arrow keys to select the recording you want to delete and follow on screen directions.



**Rewind:** Rewind through parts of a recording. Press multiple times to rewind faster.

**Play:** Begin or resume watching a recording.

**Pause:** Pause the program you are watching. While paused, the Fast Forward button will play the program frame by frame in slow motion.

**Fast Forward:** Fast forward through parts of a recording. Press multiple times to go forward faster.

**Skip Forward:** Skip forward 30 seconds while watching a recording.

**Record:** Record a program.

**Stop:** Stop watching a recording or stop a recording in progress.

**Skip Back:** Skip backwards 10 seconds while watching a recording or live TV.

**My Recordings:** Press to see a list of recorded programs. Press it again to see what is scheduled to be recorded.

**Arrows/Browse/Search/OK:** Press to navigate through the guides, menu options or to make selections.

**Guide:** Access the program guide. Press a second time for additional program information.

**Red:** Weather App

**Green:** Recent Calls

**Yellow:** Apps (Games/Weather/What's Hot)

**Blue:** Status Bar

Follow on screen prompts for use of colored buttons.

**Note:** length of "skip" features can be changed in your menu options